


## EXPLODED VIEWS &amp; PARTS LISTS




## 501R COSMETIC VIEW

Ref.	Part No.	Description	Ref.	Part No.	Description
1	6110070	Bolt, 1/4-20x3/4 Spinlock Zinc	68	3411001	Refrigerator Roll-Out Basket Retainer, RH
2	0182560	Cabinet Hinge, Top	69	3500280	Refrigerator Roll-Out Basket Glass
3	6200070	Screw, #4-24 x 3/8" Flat HD	70	3600920	Refrigerator Roll-Out Basket Glass Retainer
4	3450270	E-Ring / Retaining Ring	71	3410890	Refrigerator Roll-Out Basket Front
5	4150771	Door Hinge, Top; RH	72	4180850	Basket Assembly, Ref Roll-out
	4150772	Door Hinge, Top; LH	73	4180790	Shelf Assembly, Ref Roll-out Basket
6	3420070	Hinge Bearing	74	NLA	Refrigerator Shelf Glass - See 4180760
7	6200210	Screw, #8-32 x 1/2" Flat Head		4180760	Glass Shelf Assembly
8	6110010	Bolt, #10-24 x 1/2" Flat Head UC	75	4200840	Light Diffuser/Fan Shroud Replacement Components
9	6200010	Screw, #10-12 x 3/4" Pan HD			
10	2210701	Main Frame Angle	76	3411160	Ref Roll-Out Bskt Divider
11	6200210	Screw, #8-32 x 1/2" Flat Head	77	3411052	Vent Slide
12	2225611	Left Side Main Frame, RH Dr Swing	78	3411042	Crisper Drawer Glass
	2225612	Left Side Main Frame, LH Dr Swing	79	0200720	Cold Plate Cover / Evaporator Cover
13	0165380	Back Cover	80	1807300	Breaker Strip, 6' Length - NOTE: Must be cut to length
14	6200230	Screw, #8-18 x 1/2" Hex Head	81	1807300	Breaker Strip, 6' Length - NOTE: Must be cut to length
15	4110022	Left Base Assembly			
16	3570020	Rear Leveling Leg, #18-3/8 x 1-1/2"	82	1807300	Breaker Strip, 6' Length - NOTE: Must be cut to length
17	3570050	Leveling Leg, #18-3/8 x 1"			
18	0164770	Kickplate, 3.44 x 35.5	83	1807300	Breaker Strip, 6' Length - NOTE: Must be cut to length
19	6200050	Screw, #10-12 x 1/2" Pan HD			
20	3570030	Leveling Rod, 26-3/4"	84	3601091	Cabinet Shelf Ladder, RS
21	4110021	Right Base Assembly	85	3601092	Cabinet Shelf Ladder, LS
22	0211680	Refrigerator Fan Guard	86	2225618	Top Main Frame, RH Dr Swing
23	0211380	Refrigerator Light Diffuser Retainer		2225619	Top Main Frame, LH Dr Swing
24	6200140	Screw, #8-15 x 3/8" Truss Head	87	3410941	Crisper Slide, RS
25	3410960	Center Crisper Slide		3410942	Crisper Slide, LS
	4180940	Crisper Slide Assy; Center		4180931	Crisper Slide Assembly, RS
26	3550460	White Caplug		4180932	Crisper Slide Assembly, LS
27	3550450	Hex Insert	88	4280510	Condenser Fan Shroud Assembly
28	3430080	Roller Bushing	89	4280200	Compressor Shroud Assembly
29	3421100	Crisper Roller; Narrow	90	3012600	Control Panel - NOTE: Also order three 6230530.
30	6200740	Screw, #10-32 x 11/16" PH Flat HD UC			
31	6200450	Screw, #8 x 1" Type AR Flat	91	4180850	Basket Assembly, Ref Roll-out
32	6200450	Screw, #8 x 1" Type AR Flat	92	0165410	Kickplate Support
33	6200730	Screw, #10-16 x 3/4" PH Flat HD UC	93	6200010	Screw, #10-12 x 3/4" Pan HD
34	3421110	Crisper Roller	94	4110333	Base Assembly (w/rollers)
35	3430080	Roller Bushing	95	6110520	Adjusting Screw
36	6200210	Screw, #8-32 x 1/2" Flat Head	96	6150670	J-Nut, #10-24
37	6200210	Screw, #8-32 x 1/2" Flat Head	97	4110331	Base Rear Roller Assy
38	6200710	Screw, #8-18 x 3/8" Fillister HD	98	3550560	Straight Pin, Base Assy - .312" x 2.88"
39	2225604	Right Side Main Frame, RH Dr Swing	99	3421240	Cabinet Roller (3 per side)
	2225605	Right Side Main Frame, LH Dr Swing	100	3450620	Canoe Clip
40	6200140	Screw, #8-15 x 3/8" Truss HD	101	0166150	Kickplate, Vented
41	6200130	Screw, #8-18 x 3/4" Truss HD		4200871	Kickplate, Solid
42	3411002	Refrigerator Roll-Out Basket Retainer, LH	102	6200050	Screw, #10-12 x 1/2" Pan HD
43	6200730	Screw, #10-16 x 3/4" PH Flat HD UC	103	6200010	Screw, #10-12 x 3/4" Pan HD
44	3421110	Crisper Roller	104	6220050	Screw Grommet, 1/2" x 5/8"
45	3430080	Roller Bushing	105	6200010	Screw, #10-12 x 3/4" Pan HD
46	4151090	Crisper Tray Assembly	106	0166070	Kickplate Support
47	4180910	Crisper Drawer Assembly	107	4110333	Base Assembly (w/rollers) - Right or Left
48	2226201	Grille Top, RH Dr Swing	108	6110010	Bolt, #10-24 x 1/2" Flat Head UC
	2226202	Grille Top, LH Dr Swing	109	6200210	Screw, #8-32 x 1/2" Flat Head
49	4240500	Louvered Grille	110	3450570	Door Closer Cushion
50	6200790	Screw, #8-18 x 1/2" Black	111	3421310	Door Closer Guide
51	4151141	Cabinet Hinge, Bot; RH	112	0165970	Door Closer Guide Support
	4151142	Cabinet Hinge, Bot; LH	113	4151231	Cabinet Hinge Assembly, Bot; RH
52	6110010	Bolt, #10-24 x 1/2" Flat Head UC		4151232	Cabinet Hinge Assembly, Bot; LH
53	6110270	Bolt, #10-32 x 1/4" RD HD	114	4201113	Door Closer Assembly, RH
54	3420681	Bottom Cabinet Hinge Cam, RH		4201114	Door Closer Assembly, LH
	3420682	Bottom Cabinet Hinge Cam, LH	115	3421260	Door Closer Bearing
55	3420690	Bottom Door Hinge Cam (RH & LH)	116	3450550	E-Ring / Klipping, 5/16"
56	6110270	Bolt, #10-32 x 1/4" RD HD	117	6110070	Bolt, 1/4-20x3/4 Spinlock Zinc
57	6110010	Bolt, #10-24 x 1/2" Flat Head UC	118	3421270	Hinge Bearing, 3/8" x 5/8"
58	0182381	Door Hinge, Bottom; RH	119	4151241	Door Hinge, Bot; RH
	0182382	Door Hinge, Bottom; LH		4151242	Door Hinge, Bot; LH
59	6150140	Spring Grip Nut, 1/8"	120	6160220	Steel Spacer
60	3580110	Name Plate	121	DS90	Door Stop-90 Degree
61	3411022	Crisper Drawer		DS105	Door Stop-105 Degree
62	3411032	Crisper Front	122	3570050	Leveling Leg, #18-3/8 x 1"
63	1301900	Rear Crisper Seal	123	0183140	Cabinet Hinge Stiffener
64	4151060	Crisper Glass Assembly	124	6110450	Bolt, 1/4-20 x 1/2" Whiz Lock
65	2301601	Front Crisper Glass Seal			
66	6200700	Screw, #6-20 x 5/8" PH Flat HD SS			
67	6220320	Screw Grommet			

**501R COSMETIC VIEW**



Use prior to Serial No. M834653/P835903



Use after Serial No. M834654/P835904

