

542 DOOR VIEW

Ref.	Part No.	Description	Ref.	Part No.	Description
1	6200720	Screw, #8-18 x 1/2 PH Truss HD	21	2225416	Door Trim, Freezer Top
2	4200490	Standard Handle End Cap Replacement Components	22	3211310	Dairy Compartment Seal
	4200700	Extended Handle End Cap Replacement Components	23	3515910	Dairy Door
3	3450450	Molding Magnet - 3"	24	3421060	Dairy Compartment Center Divider
4	4130970	Handle Molding Assembly	25	4330390	Dairy Compartment Assembly
5	4130910	Door Handle Assembly	26	3601230	Dairy Compartment
	EH561	Extended Handle Assembly Set	27	3510940	Door Shelf Support, Refrigerator
6	4330440	Door Shelf Assembly, Freezer	28	4330380	Door Shelf Assembly, Refrigerator, 17"
7	3511200	Door Shelf Support, Freezer	29	3211660	Door Gasket, Refrigerator
8	3601800	Door Shelf Tray, Freezer	30	2225201	Door Trim, Side; Ref RS/Fre LS
9	3420260	Gasket Retainer, 66.875"	31	3421620	Gasket Retainer, Top & Bot Ref, 23.125"
10	4200490	Standard Handle End Cap Replacement Components	32	2225419	Door Trim, Refrigerator Bottom
	4200700	Extended Handle End Cap Replacement Components	33	3601240	Door Shelf Tray, Refrigerator
11	3421610	Gasket Retainer, Top & Bot Fre, 13.813"	34	3550490	Dairy Compartment Retainer
12	2225417	Door Trim, Freezer Bottom	35	3600851	Dairy Compartment Outer End Cap; RS
13	3211670	Door Gasket, Freezer		3600852	Dairy Compartment Outer End Cap; LS
14	2225201	Door Trim, Side; Ref RS/Fre LS	36	3600891	Dairy Compartment Inner End Cap RS
15	6180040	Pop Rivet, 3/16x1/8 Grip		3600892	Dairy Compartment Inner End Cap LS
16	3450460	Door Trim Clip	37	2225418	Door Trim, Refrigerator Top
17	3600751	Door Shelf Outer End Cap RS	38	3411490	Egg Tray
	3600752	Door Shelf Outer End Cap LS	39	4131930	Door Assembly, Freezer
18	3550440	Door Shelf Retainer	40	4131920	Door Assembly, Refrigerator
19	3600761	Door Shelf Inner End Cap RS	41	4200940	Switch Depressor
	3600762	Door Shelf Inner End Cap LS			
20	6200410	Screw, #8 x 1/2" Slot Head Hex			

542 DOOR VIEW

